

Item# KS-0107

BIKE PUMP

OWNER'S
MANUAL

KOLO
SPORTS



**Congratulations On Your Purchase of a
Kolo Sports Bike Pump Kit**

**Thank you for purchasing a Kolo Sports product.
You can rest assured that you have purchased a
high quality, Fully Warranted product.**

support@kolosports.com

WWW.KOLOSPORTS.COM

**LOCK
LEVER**

DUST CAP

**REVERSIBLE
VALVE**

**MOUNTING
BRACKET**

**VELCRO
MOUNTING
BRACKET**

**STRONG
ALLOY
CONSTRUCTION**

**ERGONOMIC
RUBBER
HANDLE**

**LOCKING
HANDLE
DESIGN**

BIKE PUMP FEATURES



**TWIST
AS SHOWN
TO LOCK
PUMP IN
HIGH
PRESSURE
MODE**

**Use in Unlocked
mode for quicker
inflation of low tires
or use in Locked
mode to inflate
tires with a higher
amount of pressure.**

REVERSIBLE PRESTA / SHRADER VALVE



Unscrew valve cover to access reversible valve. Remove valve and rotate as needed for Presta or Shrader style valve stems. Place large diameter hole outwards for Presta style valve stems or small diameter hole out for Shrader style valve stems.

PUMP INSTALLATION OPTIONS



FRONT AXLE INSTALLATION

Pump can be installed on the Front Axle by using the bracket and two screws provided in kit. Pump can also be installed on either the Top Bar or Rear Axle using the bracket and velcro strap. Now that your pump is installed, it will always be there when you need it!

TIRE INFLATION INSTRUCTIONS

This manual contains detailed instructions on how to install and use your new Kolo Sports bike pump. Read instructions carefully. For more information visit us at www.kolosports.com



1 ATTACH PUMP TO VALVE



2 RAISE LEVER TO LOCK



3 PUMP TO INFLATE TIRE

In order to inflate a low tire, first remove the valve stem cover and determine whether you have a presta or schrader style valve stem. Adjust valve as needed and attach pump to valve stem. Flip up lock lever to lock pump to valve. Extend & contract pump to inflate the low tire. When you reach the correct tire pressure, unlock and remove pump. Replace the valve stem cover.

TIRE REPAIR INSTRUCTIONS



To begin repairs, unbolt and remove wheel from bike frame. Insert the flat end of one of the tire tools in between the wheel rim and bead of tire. Pry tire tool down and hook opposite end onto one of the tire spokes which will create a gap between the rim and tire. Insert the second tire tool into the gap next to the first tire tool and slide the second tire tool around the circumference of the wheel rim. This will pop the tire off the rim and allow you remove the inner tube. Once you locate the hole in the inner tube, clean area, roughen area with sand paper, center patch above hole and press firmly. Place inner tube back into tire, place the tire back onto the rim and inflate to the correct pressure. Place wheel back into frame and tighten bolts.

BALL INFLATION INSTRUCTIONS



- 1 INSERT BALL NEEDLE AND LIFT THUMB LEVER TO LOCK THE NEEDLE INTO PLACE



- 2 INSERT NEEDLE INTO THE BALL VALVE AND PUMP TO INFLATE



BIKE PUMP KIT CONTENTS

INCLUDES:

- BIKE PUMP
- MOUNTING KIT
- PATCHES
- TIRE TOOLS
- BALL NEEDLE

TIRE
PUMP

BALL
NEEDLE

GLUELESS
PATCHES

VELCRO
STRAP

MOUNTING
BRACKET

TIRE
TOOLS

Durable Reinforced Nylon With Fiber Tire Tools Prevent Damage To Bike Rims



**PREFERRED
CUSTOMER
DISCOUNT**

THANK YOU FOR YOUR PURCHASE

**10% OFF
COUPON**

**ANY KOLO SPORTS
MERCHANDISE
COUPON CODE# 00288**

WWW.KOLOSPORTS.COM



WWW.KOLOSPO RTS.COM



QUALITY GUARANTEED

Quality is our #1 priority here
at Kolo Sports.

All Kolo Sports products
come with a Lifetime Warranty
on manufacturing defects
and a 5 year total coverage
replacement warranty on any
product that fails under
normal usage conditions.

MADE IN TAIWAN